

Parts List:



Membrane



Trim

Tools Required:



Drill Driver



Self-drilling Screws



Silicone

Step 1:

Lay the membrane on the roof of the walk-in box with the smooth, shiny side facing up. Let it hang at least 6" over each side of the walk-in box. If it's too long, you can trim it after it's installed



Step 2:

Use the drill driver to attach the trim to the wall panels with self-drilling screws:

- 1) Keep the trim level, with its top edge 4" to 4.5" from the top of the walk-in box
- 2) The screws should be no deeper than 1"
- 3) Make sure the membrane is pulled taut



Step 3:

At the corners, tuck the excess fabric under the membrane to create a neat fold. Pull it tight, then begin securing the membrane to the wall panels, following the same instructions as before



Step 4:

Use a knife to trim the excess fabric below the trim for a clean look



Step 5:

Caulk the top edge of the trim pieces with silicone.

